


















INSTALLATION MANUAL FOR HARNESS JINKER CART

Installation Step	Description	Photo A	Photo B	Photo C
Step 1	Use 18mm nut to put 005 and 002 together			
Step 2	To use U part to fix the wheel system on the cart structure 1			
Step 3	To install the seat frame sliding device 004 on both side of the cart structure 001			
Step 4	To install the spring with the seat frame and cart body			

Step 5	To install 012 seat frame on the sliding device 014			
Step 6	To install 010 on 012, arm back on seat frame, then seat bracket 003 connecting the arm back and seat frame			
Step 7	Use the self tapered screws to attach the Seat 008 onto the metal frame. Use the bolts to attach the seat back 009 onto the back of metal frame			
Step 8	To install 011 the bracket on the main body, then to install 005 the turnable device on 005			

Step 9	To install U tube 004 on 001, and then to install 013 connecting the cart body with U tube			
Step 10	To install the shafts on 016			
Step 11	The finished installation photos			

* ONCE YOU HAVE FULLY ASSEMBLED YOUR CART AND READY TO USE, ADJUST THE LENGTH OF THE SHAFTS TO SUITE YOUR HORSE IN THE STYLE OF HARNESS YOU WILL BE DRIVING THEM IN. ONCE YOU HAVE ADJUST THE LENGTHS OF THE SHAFTS IT IS HIGHLY RECOMMENDED THAT YOU FASTEN THE TWO NUTS ON THE U-TUBE END WE PROVIDED. THIS IS ESPECIALLY IMPORTANT IF YOU ARE USING THE QUICK HITHCH SYTLE OF HARNESS.